




1

Lamp Installation




Attention

Before any maintenance switch off the main power.

Luminaires are available for recessed tracks and surface tracks

2



Adjust the fixture for proper position:



You can move the fixture from side to side on the track to adjust the proper position.

Adjust the length of the wire:

Press the tension head inward with one hand, while the other hand pushes or pulls the wire inward or outward to adjust to the proper position, the adjustment range is 800mm.

3

Luminaire Removal



Keep pressing the buttons on both sides of the fixture and press outward at the same time, then you can take out the fixture.